

T e c h n i c a l P r o c e d u r e

LifeBook P1610

Hard Drive Replacement

ESD Precautions are required when working on this LifeBook computer.


Make sure the LifeBook is turned off before beginning this procedure.




1. Turn the LifeBook over and remove the battery




2. Extract these 3 screws from the Hard Disk Drive cover and lift it off.




3. Release the cable by flipping the latch up.



4. Lift the Drive out.



5. Transfer the ribbon cable from the defective drive to the new drive and insert the new drive.



6. Press the latch down to lock the cable into place.



7. Replace the Drive cover and secure it with 3 screws.



8. Replace the battery.